# Wireless Manager ME5.5/ME6.0.1/ME6.0.2/ME6.2/ME6.3 · ME6.4 Function Chart

© Panasonic Corporation 2019

### Wireless Manager Software Compatibility

Series	Applicable Model Number	Wireless Manager ME 6.0.1		Wireless Manager ME 6.0.2		Wireless Manager ME 6.2		Wireless Manager ME 6.3		Wireless Manager ME 6.4	
		Wired LAN	Wireless LAN	Wired LAN	Wireless LAN	Wired LAN	Wireless LAN	Wired LAN	Wireless LAN	Wired LAN	Wireless LAN
BF1 Series	TH-80BF1 TH-65BF1 TH-50BF1	Supported	Supported	Supported	Supported	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended)
_FB Series	TH-80LFB70 TH-65LFB70 TH-50LFB70	Supported	Supported	Supported	Supported	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended)
LFC Series	TH-80LFC70 TH-65LFC70 TH-50LFC70	Supported	Supported	Supported	Supported	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended
PB1 Series	TH-50PB1 (*1)	Supported	Supported	Supported	Supported	Supported	Supported	Not Supported	Not Supported	Not Supported	Not Supported
	TH-65PB1 (*1)	Supported	Supported	Supported	Supported	Supported	Supported	Not Supported	Not Supported	Not Supported	Not Supported
	TH-85PB1 (*1)	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended)	Not Supported	Not Supported	Not Supported	Not Supported
	TH-103PB1 (*1)	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended)	Not Supported	Not Supported	Not Supported	Not Supported
PB2 Series	TH-50PB2 (*1)	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended)	Not Supported	Not Supported	Not Supported	Not Supported
	TH-65PB2 (*1)	Supported	Supported	Supported	Supported	Supported (Recommended)	Supported (Recommended)	Not Supported	Not Supported	Not Supported	Not Supported
PF50 Series	TH-42PF50 (*1)	Supported	Supported	Supported	Supported	Supported	Supported	Not Supported	Not Supported	Not Supported	Not Supported
	TH-50PF50 (*1)	Supported	Supported	Supported	Supported	Supported	Supported	Not Supported	Not Supported	Not Supported	Not Supported
	TH-65PF50 (*1)	Supported	Supported	Supported	Supported	Supported	Supported	Not Supported	Not Supported	Not Supported	Not Supported

\* For PB Series users.

When using Wireless Manager to wirelessly show the image from your PC on the display, the Electronic Pen for the Interactive Display cannot be used (expect when using the built-in whiteboard function).

#### **Wireless Connection Modes**

Wireless Setting	Applicable Software	Connection Mode	TH-80BF1 TH-65BF1 TH-50BF1	TH-80LFB70 TH-65LFB70 TH-50LFB70	TH-80LFC70 TH-65LFC70 TH-50LFC70	TH-65PB1 TH-50PB1	TH-103PB1 TH-85PB1	TH-65PB2 TH-50PB2	TH-65PF50 TH-50PF50 TH-42PF50
[S-MAP]	Wireless Manager ME 6.0.1 Wireless Manager ME 6.0.2	Ad-Hoc	N/A	N/A	N/A	Yes	Yes	Yes	Yes
[0 ]	Wireless Manager ME 6.2	7.60							
	Wireless Manager ME 6.0.1		N/A	N/A	N/A	Yes	Yes	Yes	Yes
[1] [2] [3] [4]	Wireless Manager ME 6.0.2	Ad-Hoc							
	Wireless Manager ME 6.2								
	Wireless Manager ME 6.0.1	Ad-Hoc	Yes (*4)	Yes (*4)	Yes (*4)	Yes	Yes	Yes	Yes
	Wireless Manager ME 6.0.2	Infrastructure							
User1] [User2] [User3]	Wireless Manager ME 6.2	(*3)							
	Wireless Manager ME 6.3	Infrastructure	Yes	Yes	Yes	N/A	N/A	N/A	N/A
	Wireless Manager ME 6.4	Tilli asti ucture							
[S-DIRECT]	Wireless Manager ME 6.0.1								
	Wireless Manager ME 6.0.2		Yes	Yes	Yes	N/A	Yes	Yes	N/A
	Wireless Manager ME 6.2	Infrastructure							
	Wireless Manager ME 6.3		Yes	Yes	Yes	N/A	N/A	N/A	N/A
	Wireless Manager ME 6.4								
[M-DIRECT]	Wireless Manager ME 6.0.1		Yes	Yes	Yes	N/A	Yes	Yes	N/A
	Wireless Manager ME 6.0.2								
	Wireless Manager ME 6.2	Infrastructure							
	Wireless Manager ME 6.3		Yes	Yes	Yes	N/A	N/A	N/A	N/A
	Wireless Manager ME 6.4								

## **Display Method/Applicable Functions**

Display Mode		Wireless Manager ME 6.0.1	Wireless Manager ME 6.0.2	Wireless Manager ME 6.2	Wireless Manager ME 6.3	Wireless Manager ME 6.4	
Live Mode	-	Yes	Yes	Yes	Yes	Yes	
	4-screen multi style	Yes (*6)	Yes (*6)	Yes (*6)	Yes	Yes	
Multi Live Mode	4-screen index style	Yes (*6)	Yes (*6)	Yes (*6)	Yes	Yes	
	16-screen index style	Yes (*6)	Yes (*6)	Yes (*6)	Yes	Yes	
Multi-Unit Live Mode	-	Yes	Yes	Yes	Yes	Yes	
Multi-Unit Multi Live Mode	4-screen multi style	N/A	N/A	N/A	N/A	N/A	
Audio Output (*7)(*8)		Yes	Yes	Yes	Yes	Yes	
Search Functions	IP Address Search	Yes	Yes	Yes	Yes	Yes	
	Domain Name Search	N/A	N/A	N/A	N/A	N/A	
	ID Search	N/A	N/A	N/A	N/A	N/A	
Convenient Functions	Area Designation Transmission	N/A	N/A	N/A	N/A	Yes	
	Secondary Display Transmission (*9)	N/A	N/A	N/A	N/A	N/A	
	AV Mute	N/A	N/A	N/A	N/A	N/A	
	Pointer	N/A	N/A	N/A	N/A	N/A	
	Web Control	Yes	Yes	Yes	Yes	Yes	
	Sender Name Display (in Multi Live Mode)	Yes	Yes	Yes	Yes	Yes	

- \*1 The optional Wireless Module (ET-WM200) is required for wireless LAN connection.
- \*2 Ad-Hoc modes are not supported. Usable only in Infrastructure mode. \*3 Usable by selecting Ad-Hoc and Infrastructure in [User] mode.
- \*4 Usable only Infrastructure in User mode.
- \*5 Multi Live Style cannot be selected from the application (selectable by using the remote control of the display).
- \*6 Multi Live Style cannot be selected from the application for the PF50 Series or the TH-65PB1/TH-50PB1 (selectable by using the remote control of the display).
- \*7 There are not built-in speakers in the PF50 Series and the TH-65PB1/50PB1. Please use optional external speakers. \*8 Audio output is possible only in Live mode. However, this software must be installed in the computer (i.e., the driver must be installed).
- \*9 Macintosh is not supported.

## **Limitations When Using Without Installation**

- The function to output audio together with video in Live mode cannot be used.
- The Secondary Display Transmission function cannot be used.